

HERMES

Homing Pigeon Breeding Boxes

ASSEMBLY INSTRUCTIONS FOR PERCH BOXES WITH NESTING HOLES

1



If the box is delivered with a rear panel, insert the panel in the grooves at the back of the side panels. Then, from the top to the bottom, push the rear crossbars with the dimensions 19 x 27 mm onto the metal bolts on the side panels. 5 bars in total.

2



Hang the base panels in the holes provided for this.

3



The beech wood perch bars are marked with the numbers (I) and (II) on the front face. The bars marked with (I) are required for the bottom, middle and top section rows! For the second and fourth rows from the top, the perch bars marked with 2.

HERMES

Homing Pigeon Breeding Boxes

ASSEMBLY INSTRUCTIONS FOR PERCH BOXES WITH NESTING HOLES

4



The coloured rotatable panels are likewise marked with the numbers 1 and 2. The panels marked with (1) are required for the bottom, middle and top section rows. For the second and fourth rows from the top, the panels marked with 2.

5



Fit the first coloured panel marked with (1) as shown in the picture.
Tip: A colour scheme is printed on the coloured panel packaging.

6



Fit the crossbars with the two holes onto the metal bolts on the side panels and onto the top dowel of the rotatable panel.

HERMES

Homing Pigeon Breeding Boxes

ASSEMBLY INSTRUCTIONS FOR PERCH BOXES WITH NESTING HOLES

7



Fit all the rotatable panels marked with the number 1 into the bottom section rows.

8



Now the wire meshes are inserted. The folds must point downwards. Tip: Insert the wire meshes before the coloured rotatable panels are fitted.



9



Now fit the perch bars marked with (II) in the second row from the bottom.

HERMES

Homing Pigeon Breeding Boxes

ASSEMBLY INSTRUCTIONS FOR PERCH BOXES WITH NESTING HOLES



10

Fit the perch bars so that the two holes in the 32 mm grid pattern point to the front. (See the picture.).



11

The coloured rotatable panels are likewise marked with the numbers 1 and 2. The panels marked with (I) are required for the bottom, middle and top section rows. For the second and fourth rows from the top, the panels marked with 2!



12

Now fit all the rotatable panels marked with (II) and fit the crossbars over the panels as done before.

HERMES

Homing Pigeon Breeding Boxes

ASSEMBLY INSTRUCTIONS FOR PERCH BOXES WITH NESTING HOLES

13



Once again, the bars marked with (I) and the rotating panels marked with 1 are fitted into the middle row.

14



Repeat this for the last two rows. Again, the parts marked with the numbers 2 (II) are fitted into the fourth row from the bottom and in the top row the parts marked with the number 1 (I).

15



Insert the floors.

HERMES

Homing Pigeon Breeding Boxes

ASSEMBLY INSTRUCTIONS FOR PERCH BOXES WITH NESTING HOLES

16



The box is now fully assembled. It must still be aligned using a spirit level and then be firmly screwed to the back wall.

17



The coloured rotatable panels can now also be rotated through 90°. The section can then also be used for two separate pigeons.